


SUBJ: Diverter Gate Adjustment Procedure

Helpful Hints:

This adjustment procedure is important. Unlike adjusting your flipper bats, adjusting the gate is done opposite. With the **Power Turned OFF** and the *Playfield raised, at rest against the Backbox, perform the following:*




Step 1: Under the Playfield, using a 5/32" Allen Wrench, loosen the Set-Screw on the Crank Bar *just enough so that the Diverter Paddle can move with a gentle amount of force.* **Ref. Fig. 1-A**.

Step 2: Above the Playfield, position the Diverter Paddle to the Right Side Flat Rail so they touch *(opening the gate to the Left Orthanc Tower)*. **Ref. Fig. 2**. With your finger, hold the gate in this position until *Step 3* is performed.

Step 3: Under the Playfield, push the Diverter Coil Plunger into the Coil Sleeve. **Reference Fig. 1-B**. With your finger, continue holding in the plunger and release the Diverter Gate (**Fig. 2**) to perform *Step 4*. If the Gate moves, refer to *Step 1* and retighten just enough to hold in position (**Fig. 2**).

Step 4: Tighten the Set-Screw on the Crank Bar. **Reference Fig. 1-A**.

Step 5: Check above the playfield to ensure the Diverter Paddle Gate in the "Rest Position" is as close to the Left Flat Rail as possible without touching it. **Reference Fig. 3.**



Please or eMail with any questions or comments at the below numbers or address.

• 2020 Janice Ave. • Melrose Park, IL 60160 • Tel 708-345-7700 (Option 1) • Toll-Free (USA/Canada) 1-800-542-5377 • Fax 708-345-7889 •

Received via Fax? For a better copy, download from our website: www.sternpinball.com/bulletins.htm S.B. Nº 147 Page 1 of 1 Want Service Bulletins by eMail? Request by eMail: parts.service@sternpinball.com